


Anziehvorschrift für Zylinderkopf	219.612	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		

Schraubenkopf / Head shape
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



759.370
M 10x1,5x99/113



Anziehen/ Tightening/ Serrage/ Apriete	* 20 Nm ▶ 100° ● 3 min	Pos. 7-10: □ 20 Nm + 110°
	□ 20 Nm + 110° Pos. 1,2: □ 20 Nm + 110° Pos. 3-6: □ 20 Nm + 110°	

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
▶	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 80 mm; $\frac{1}{2}$: 1,27 mm

Mot: K7M 702, 703, 704, 710, 720, 744, 745, 746
K7J 700, 701

1,6 Ltr. 55 - 66 KW

Clio, Kangoo, Megane

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

219.612